



SHENZHEN FENDA TECHNOLOGY CO.,LTD.GUANGDONG,PRC
 ADD: Fenda Hi-Tech Park,Zhouzhi Road,Shiyao, Baoan, Shenzhen, Guangdong, PRC
 Tel: +86-755-27486661 (800 line) Fax: +86-755-27333777 P.C.: 518108



2.0 Computer Multimedia Speaker



Safety precautions

- Never push objects of any kind (needles, hair-pins, coins, insects) into this system.
- Do not put the system in damp circumstances, prevent from ingress of moisture and dust. (Do not place flower vases and other objects on it).
- Prevent the system from heating. (Do not install the system near heat sources and prevent it from direct sunlight).
- Do not use petrol, alcohol and other solvents when cleaning, as they may damage stained surface. Clean only with dry soft cloth.
- In order to avoid electric shock and other accidents, never open the back cover for repair without any professional guidance.
- Switch off the power and take off the plug from the power jack when the system is not on work.

Notes:
 The specifications may be changed without preliminary notice.

Locating

- * Place the speakers symmetrically to the listeners to the distance not less than one metre.
- * Port tube is located at the back panel of the speaker cabinet, please locate it about 20—30 cm from the wall or other object.

Connection diagram

Safety Instructions

1. Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
2. WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
3. WARNING: The mains plug is used as disconnect device, the disconnect device shall remain readily operable.
4. Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.
5. Frequency: 2.402GHz-2.48GHz
6. The Max. transmit power: 10dBm

Control panel functions:

⏻ : a. Long press to Power ON/OFF the unit.
 ⏻ : b. Short press to select Bluetooth, AUX, USB play and Optical mode.
 + : Press it to increase the volume level
 - : Press it to decrease the volume level

Bluetooth mode

1. Active "Bluetooth" function on your device and search for "Fenda R23BT". Enter "0000" if your device asks for the PIN code.
2. After pairing successfully, blue LED bright, and ready for playing music. Recommend to adjust suitable volume before playing music.

Notice: After switch to Bluetooth source, the unit will automatically search the Bluetooth device and connect it. If the device paired before, it will enter pairing mode automatically and the blue LED will flash quickly. Bluetooth device should active "Bluetooth" function during pairing and search for "Fenda R23BT".

Bluetooth pairing

Switch to Bluetooth mode, R23BT will automatically search the Bluetooth device. If the device paired before, R23BT will connect automatically. If can't find paired device, R23BT will enter pairing mode automatically, bluetooth LED flashes quickly.

1. Active "Bluetooth" function on your device and search for "Fenda R23BT". Enter "0000" if your device asks for the PIN code.
2. After pairing successfully, bluetooth LED will be bright, and ready for playing music. Recommend to adjust suitable volume before playing music.

Remote Control

- ⏻ Standby: Short press to power on/off the unit
- ⏻ Mute: Short press to mute or unmute
- + Volume increase: Press to increase volume level
- ⏮ Previous song: Under USB and Bluetooth mode, short press to select previous song
- ⏭ Next song: Under USB and Bluetooth mode, short press to select next song
- Volume decrease: Press to decrease volume level
- Treble mode: Short press "Treble" first, then press volume increase or volume decrease to adjust "Treble" level
- BASS mode: Short press "BASS" first, then press volume increase or volume decrease to adjust "BASS" level
- AUX: AUX mode: Short press to select AUX mode
- USB: USB mode: Short press to select USB play mode
- OPT: Optical mode: Short press to select Optical mode
- Bluetooth mode: Short press to select Bluetooth mode

Package contents

- Speakers ----- 1set
- Operation Manual ----- 1pc
- 3.5mm to 3.5mm stereo cable ----- 1pc
- 3.5mm to RCA stereo cable ----- 1pc (optional)
- Connection Cable ----- 1pc
- Remote control ----- 1pc

Specification

- Power output ----- 20W x2
- Driver units:
 - woofer ----- 4" 6Ω
 - tweeter ----- 1" 8Ω
- Separation ----- > 40dB
- S/N Ratio ----- > 70dB
- Frequency Response ----- 65Hz~20KHz
- Power input ----- 100-240V~50/60Hz 0.3A
- Product dimensions ----- W162xD135xH238mm
- Product net weight ----- 3.5kg

F&D WARRANTY CARD
 END-USER'S COPY
 WARRANTY REGISTRATION CERTIFICATE

Mr./Mrs/Ms First Name: _____
 Last Name: _____
 Address: _____
 Contact No.: _____
 Product Name: _____
 Model No.: _____
 Serial No.: _____
 Date Purchased: _____
 Invoice No.: _____
 Retail Outlet Where Purchased: _____

(Please print the name & address)

SECTION 1

WARRANTY TERMS & CONDITIONS

The warranty will be effective only if the warranty card is completed and returned to the company within 14 days from the date of purchase. We guarantee the provision of free services of **F&D** product within the warranty period from its date of purchase from our Authorised Dealer.

The period and conditions of our warranty service are as follow:

1. The warranty covers services by our **F&D** Authorised Dealer. This warranty card together with the receipt must be presented when servicing is required. This warranty card is irreplaceable in the event of loss.
2. Repair services will be provided for defects arising from normal usage for the following period, commencing from the date of purchase from our **F&D** Authorised Dealer. (Parts would be replaced when necessary)
 - A. Parts:..... 1 year
 - B. Technical service free..... 1 year
3. Under the following circumstances, service and parts will be chargeable even within the warranty period:
 - A. Failure to present the warranty card and receipt when servicing is required. Full particulars not clearly shown or alterations made against the actual information. For e.g.: Alteration of the date of purchase, serial numbers-altered or removed.
 - B. This unit being tampered with, altered in any way by any unauthorised technicians or which has been subjected to misuse, negligence or accident. This guarantee does not cover damage occurring in transit by or from the customer.
 - C. The defect is caused by the attack of household pests, fire, lighting, natural disasters, pollution, abnormal voltage or the usage of generator.

Shenzhen Fenda Technology Co., Ltd.
 Add: Fenda Hi-Tech Park, Zhouzhi Road, Shiyao, Baoan, Shenzhen, China
 P.C.: 518108 Http://www.fenda.com

F&D WARRANTY CARD
 DISTRIBUTOR'S COPY
 WARRANTY REGISTRATION CERTIFICATE

Mr./Mrs/Ms First Name: _____
 Last Name: _____
 Address: _____
 Contact No.: _____
 Product Name: _____
 Model No.: _____
 Serial No.: _____
 Date Purchased: _____
 Invoice No.: _____
 Retail Outlet Where Purchased: _____

(Please print the name & address)

SECTION 2



WARRANTY TERMS & CONDITIONS

The warranty will be effective only if the warranty card is completed and returned to the company within 14 days from the date of purchase. We guarantee the provision of free services of **F&D** product within the warranty period from its date of purchase from our Authorised Dealer.

The period and conditions of our warranty service are as follow:

1. The warranty covers services by our **F&D** Authorised Dealer. This warranty card together with the receipt must be presented when servicing is required. This warranty card is irreplaceable in the event of loss.
2. Repair services will be provided for defects arising from normal usage for the following period, commencing from the date of purchase from our **F&D** Authorised Dealer. (Parts would be replaced when necessary)
 - A. Parts:..... 1 year
 - B. Technical service free..... 1 year
3. Under the following circumstances, service and parts will be chargeable even within the warranty period:
 - A. Failure to present the warranty card and receipt when servicing is required. Full particulars not clearly shown or alterations made against the actual information. For e.g.: Alteration of the date of purchase, serial numbers-altered or removed.
 - B. This unit being tampered with, altered in any way by any unauthorised technicians or which has been subjected to misuse, negligence or accident. This guarantee does not cover damage occurring in transit by or from the customer.
 - C. The defect is caused by the attack of household pests, fire, lighting, natural disasters, pollution, abnormal voltage or the usage of generator.

Shenzhen Fenda Technology Co., Ltd.
 Add: Fenda Hi-Tech Park, Zhouzhi Road, Shiyao, Baoan, Shenzhen, China
 P.C.: 518108 Http://www.fenda.com



		时 间	20200715	订 单 号	试产	外尺寸/套装数	200X130MM(成型) 400x130mm(展开)
品 牌	FD	公司型号	R23BT	客户型号	R23BT	材质/厚度	105g铜版纸
版 本	A0	设计内容	说明书	料 号		盒型/页码/条码	7P
电 子 软 件		结 构 电 声		业 务		爆破/边压	
设计者	张志锋	标 准 化	李洪波	项 目 经 理 产 品 经 理		印刷/表面处理	白底黑字
备 注	此物料刀模同前料号： 印刷颜色同：					工 艺 / 单 双 泊 / AB 同 版	书 钉
						公 差 / 用 量	公差±0.1mm 用量1