

展开尺寸: 290*210mm

工艺: 双面印刷, 折页

2.0 COMPUTER MULTIMEDIA SPEAKER



User Manual



MODEL NO.:V320

F&D WARRANTY CARD
END-USER'S COPY
WARRANTY REGISTRATION CERTIFICATE

Mr./Mrs/Ms First Name: _____
Last Name: _____
Address: _____
Contact No.: _____
Product Name: _____
Model No.: _____
Serial No.: _____
Date Purchased: _____
Invoice No.: _____
Retail Outlet Where Purchased: _____

(Please print the name & address)

SECTION 1

F&D WARRANTY CARD
DISTRIBUTOR'S COPY
WARRANTY REGISTRATION CERTIFICATE

Mr./Mrs/Ms First Name: _____
Last Name: _____
Address: _____
Contact No.: _____
Product Name: _____
Model No.: _____
Serial No.: _____
Date Purchased: _____
Invoice No.: _____
Retail Outlet Where Purchased: _____

(Please print the name & address)

SECTION 2



www.fenda.com

WARRANTY TERMS & CONDITIONS

The warranty will be effective only if the warranty card is completed and returned to the company within 14 days from the date of purchase. We guarantee the provision of free services of F&D product within the warranty period from its date of purchase from our Authorised Dealer.

The period and conditions of our warranty service are as follows:

1. The warranty covers services by our F&D Authorised Dealer. This warranty card together with the receipt must be presented when servicing is required. This warranty card is irreplaceable in the event of loss.

2. Repair services will be provided for defects arising from normal usage for the following period, commencing from the date of purchase from our F&D Authorised Dealer. (Parts would be replaced when necessary)

- A. Parts:..... 1 year
- B. Technical service free..... 1 year

3. Under the following circumstances, service and parts will be chargeable even within the warranty period:

- A. Failure to present the warranty card and receipt when servicing is required. Full particulars not clearly shown or alterations made against the actual information. For e.g.: Alteration of the date of purchase, serial numbers-altered or removed.
- B. This unit being tampered with, altered in any way by any unauthorised technicians or which has been subjected to misuse, negligence or accident. This guarantee does not cover damage occurring in transit by or from the customer.
- C. The defect is caused by the attack of household pests, fire, lighting, natural disasters, pollution, abnormal voltage or the usage of generator.

Shenzhen Fenda Technology Co., Ltd.
Add : Fenda Hi-Tech Park, Zhoushi Road, Shiyuan, Baoan, Shenzhen, China
P.C. : 518108 Http://www.fenda.com

- 1. Read Instructions — All the safety and operating instructions should be read before the appliance is operated.
- 2. Read Instructions — The operating instructions should be retained for future reference.
- 3. Follow Instructions — All operating and user instructions should be followed.
- 4. Water And Moisture — The appliance should not be used near water — for example, near a bathtub, washbowl, kitchen sink, Laundry tub, in a wet basement, or near a swimming pool, ect. It should not be exposed to dripping or splashing water, and no Objects filled with liquid, such as a vase, should be placed on the appliance.
- 5. Outdoor Use — Warning: To reduce the risk of fire of electric shock, do not expose this appliance to rain or moisture.
- 6. Location — The appliance should be installed in a stable location.
- 7. Ventilation — The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; Or placed in a built-in installation, such as a closed bookcase or cabinet that may impede the flow of air through the ventilation openings.
- 8. Heat — The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.

FEATURES

- Built-in audio amplifier.
- Adaptable to device with audio output, such as personal computer, MP3 player, etc.
- Powered by computer USB port.

SYSTEM COMPOSITION

- 1. Speaker 1pair
- 2. Operation manual 1 pc
- Warranty Card

SPECIFICATION

Power output: 2W+2W
Speaker unit 2" full range driver
Input: 5V=1A
Impedance: 4ohm
Frequency response: 24Hz - 20KHz

signal input: 3.5mm stereo jack signal cable
Separation: ≥ 35dB
S/N: ≥ 65dB
Speaker dimension: W84XD71XH152mm
Net weight: 0.60kg

WARRANTY TERMS & CONDITIONS

The warranty will be effective only if the warranty card is completed and returned to the company within 14 days from the date of purchase. We guarantee the provision of free services of F&D product within the warranty period from its date of purchase from our Authorised Dealer.

The period and conditions of our warranty service are as follows:

1. The warranty covers services by our F&D Authorised Dealer. This warranty card together with the receipt must be presented when servicing is required. This warranty card is irreplaceable in the event of loss.

2. Repair services will be provided for defects arising from normal usage for the following period, commencing from the date of purchase from our F&D Authorised Dealer. (Parts would be replaced when necessary)


- A. Parts:..... 1 year
- B. Technical service free..... 1 year

3. Under the following circumstances, service and parts will be chargeable even within the warranty period:

- A. Failure to present the warranty card and receipt when servicing is required. Full particulars not clearly shown or alterations made against the actual information. For e.g.: Alteration of the date of purchase, serial numbers-altered or removed.
- B. This unit being tampered with, altered in any way by any unauthorised technicians or which has been subjected to misuse, negligence or accident. This guarantee does not cover damage occurring in transit by or from the customer.
- C. The defect is caused by the attack of household pests, fire, lighting, natural disasters, pollution, abnormal voltage or the usage of generator.

Shenzhen Fenda Technology Co., Ltd.
Add : Fenda Hi-Tech Park, Zhoushi Road, Shiyuan, Baoan, Shenzhen, China
P.C. : 518108 Http://www.fenda.com

INSTALLATION GUIDE



Operation:

- 1. Switch on the computer.
- 2. Connect the USB power input and computer USB port by power cable provided. And then the power indicator will be turn on.
- 3. Connect the 3.5mm Line in connector to the audio output jack of audio source.
- 4. Turn the volume control knob clockwise to increase the volume level. Or turn anti-clockwise to decrease the volume level