



SINCE 1993

F&D

W26  
User manual

**CAUTION** 1


- All the safety and operating instructions should be read before the appliance is operated.
- All operating and user instructions should be followed.
- The appliance should not be used near water — for example, near a bathtub, washbowl, kitchen sink, Laundry tub, in a wet basement, or near a swimming pool etc. It should not be exposed to dripping or splashing water, and no Objects filled with liquid, such as a vase, should be placed on the appliance.
- Warning: To reduce the risk of fire of electric shock, do not expose this appliance to rain or moisture.
- The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; Or placed in a built-in installation, such as a closed bookcase or cabinet that may impede the flow of air through the ventilation openings.

**PACKAGE CONTENTS**


Speaker	1pc
Operation manual	1pc
USB cable	1pc



**BUTTON CONTROLS** 2



- Power ON/OFF
- Volume decrease
- Play/Pause FM Scan/Pairing
- Volume increase
- Source



**Power ON/OFF** :

a. Long press to Turn ON the unit  
b. Short press to Turn OFF the unit

**Volume decrease** :

Short press to decrease the volume  
Under FM mode, long press to select previous channel  
Under TF/Bluetooth mode, Long press to select previous song

**Play/Pause, Pairing and auto scan** :

Under TF/Bluetooth mode, short press to play or pause music  
Under FM mode, Long press to start Auto search & this will store the found frequencies(channels) automatically.  
Under Bluetooth mode, Long press to entering pairing mode, the Blue LED will flash fast.

**Volume Increase** :

Short press to increase the volume  
Under FM mode, long press to select next channel  
Under TF/Bluetooth mode, Long press to select next song

**Source** :

Short press to select Bluetooth, TF card, FM and AUX mode

**F&D WARRANTY CARD**

**END-USER'S COPY**

**WARRANTY REGISTRATION CERTIFICATE**

Mr./Mrs/Ms First Name: \_\_\_\_\_

Last Name: \_\_\_\_\_

Address: \_\_\_\_\_

Contact No.: \_\_\_\_\_

Product Name: \_\_\_\_\_

Model No.: \_\_\_\_\_

Serial No.: \_\_\_\_\_

Date Purchased: \_\_\_\_\_

Invoice No.: \_\_\_\_\_

Retail Outlet Where Purchased: \_\_\_\_\_

(Please print the name & address)

**SECTION 1**

**F&D WARRANTY CARD**

**DISTRIBUTOR'S COPY**

**WARRANTY REGISTRATION CERTIFICATE**

Mr./Mrs/Ms First Name: \_\_\_\_\_

Last Name: \_\_\_\_\_

Address: \_\_\_\_\_

Contact No.: \_\_\_\_\_

Product Name: \_\_\_\_\_

Model No.: \_\_\_\_\_

Serial No.: \_\_\_\_\_

Date Purchased: \_\_\_\_\_

Invoice No.: \_\_\_\_\_

Retail Outlet Where Purchased: \_\_\_\_\_

(Please print the name & address)

**SECTION 2**

**WARRANTY TERMS & CONDITIONS**

\*\*\*\*\*

The warranty will be effective only if the warranty card is completed and returned to the company within 14 days from the date of purchase. We guarantee the provision of free services of F&D product within the warranty period, from its date of purchase from our Authorised Dealer. The period and conditions of our warranty service are as follow:

- The warranty covers services by our F&D Authorised Dealer. This warranty card together with the receipt must be presented when servicing is required. This warranty card is irreplaceable in the event of loss.
- Repair services will be provided for defects arising from normal usage for the following period, commencing from the date of purchase from our F&D Authorised Dealer. (Parts would be replaced when necessary)
  - Parts:..... 1 year
  - Technical service free..... 1 year
- Under the following circumstances, service and parts will be chargeable even within the warranty period:
  - Failure to present the warranty card and receipt when servicing is required.

Full particulars not clearly shown or alterations made against the actual information.

For e.g.: Alteration of the date of purchase, serial numbers-altered or removed.

  - This unit being tampered with, altered in any way by any unauthorised technicians or which has been subjected to misuse, negligence or accident. This guarantee does not cover damage occurring in transit by or from the customer.
  - The defect is caused by the attack of household pests, fire, lighting, natural disasters, pollution, abnormal voltage or the usage of generator.

Shenzhen Fenda Technology Co., Ltd.  
Add : Fenda Hi-Tech Park, Zhoushi Road, Shiyan, Baoan, Shenzhen, China  
P.C. : 518108 Http://www.fenda.com

**WARRANTY TERMS & CONDITIONS**

\*\*\*\*\*

The warranty will be effective only if the warranty card is completed and returned to the company within 14 days from the date of purchase. We guarantee the provision of free services of F&D product within the warranty period, from its date of purchase from our Authorised Dealer. The period and conditions of our warranty service are as follow:

- The warranty covers services by our F&D Authorised Dealer. This warranty card together with the receipt must be presented when servicing is required. This warranty card is irreplaceable in the event of loss.
- Repair services will be provided for defects arising from normal usage for the following period, commencing from the date of purchase from our F&D Authorised Dealer. (Parts would be replaced when necessary)
  - Parts:..... 1 year
  - Technical service free..... 1 year
- Under the following circumstances, service and parts will be chargeable even within the warranty period:
  - Failure to present the warranty card and receipt when servicing is required.

Full particulars not clearly shown or alterations made against the actual information.

For e.g.: Alteration of the date of purchase, serial numbers-altered or removed.

  - This unit being tampered with, altered in any way by any unauthorised technicians or which has been subjected to misuse, negligence or accident. This guarantee does not cover damage occurring in transit by or from the customer.
  - The defect is caused by the attack of household pests, fire, lighting, natural disasters, pollution, abnormal voltage or the usage of generator.

Shenzhen Fenda Technology Co., Ltd.  
Add : Fenda Hi-Tech Park, Zhoushi Road, Shiyan, Baoan, Shenzhen, China  
P.C. : 518108 Http://www.fenda.com

**SHENZHEN FENDA TECHNOLOGY CO., LTD.**

**ADD: Fenda Hi-Tech Park, Zhoushi Road, Shiyan, Baoan, Shenzhen, China**

**Baoan, Shenzhen, China**

**Tel: +86-755-27353888 (800 Line)**

**Fax: +86-755-27353777**

**P.C: 518108**

**BLUETOOTH PAIRING** 3

Turn ON the W26 & this will auto search the available Bluetooth device.

- Turn ON the "Bluetooth" function on your device (Mobile phone or smart devices) and search for "Fenda W26". Enter "0000" if your device asks for the PIN code to connect with W26.
- Once the device is paired, at next Turn ON, W26 will auto search the Bluetooth device & will connect to paired one automatically.
- If can't find the paired device, W26 will enter in to pairing mode automatically.

**Specifications**


Power Output: 12W  
S/N Ratio: ≥75dB  
Separation: ≥40dB  
Speaker unit: 1.75" 4Ω  
Power Output: 5V = 1A  
Frequency response: 20Hz-20KHz  
Product dimension: W189 x D59 x H64mm  
Rechargeable Li-ion Battery: 4400mAh

**SAFETY INSTRUCTION** 4

- Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
- WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
- CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- The batter(battery or batteries of battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.



- Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.
- Frequency: 2.402GHz-2.48GHz
- The Max. transmit power: 10 dBm



展开尺寸	350X120MM
成型尺寸	70X120MM
材质要求	108g铜版纸
印刷要求	单黑正反印刷
工艺要求	无处理
页码数(页)	折页

<b>F&amp;D 奋达科技</b>		时 间	20191108	订单号	FE19277
品 牌	<b>F&amp;D</b>	公司型号	W26	客户型号	W26
版 本	A0	设计内容	说明书	料 号	17.7.030.2047
电 子 软 件	/	结 构 电 声	/	PLM文档编号	/
设计者	杨改改	标 准 化	/	项 目 经 理	/
复 核	/	业 务	/	产 品 经 理	/
				核 准	/